

KEYLINES DO NOT PRINT
ART AT 100%



FRONT

1. Locate hole in tube.
2. Remove moisture from area to be patched and roughen slightly with sandpaper.
3. Spread glue thinly over area the same size as patch to be used.
4. When glue has completely dried, remove foil backing from patch taking care not to touch the patch itself.
5. Apply patch to glued area and apply pressure over entire surface of patch for best adhesion.
6. Tube is now ready for use.

Tech Support Line 1-800-553-8324

BACK