

PERFORMANCE[®]**Forté[®]**
STOMP Pedal

Congratulations on your purchase of Forté STOMP Pedals.
To install and adjust your new pedals you will need:

- 15mm pedal wrench
- 2mm hex wrench

Pedal Installation

The right pedal (*marked R*) is installed in a clockwise direction. The left pedal (*marked L*) is installed in a counterclockwise direction.

1. Grease the axle threads prior to installation.
2. Use a 15mm pedal wrench to install and tighten the pedals. Tighten to a minimum of 300 inch/lbs. of torque.
3. To adjust or remove the traction pins, use a 2mm hex wrench.



Performance, Inc.
One Performance Way
Chapel Hill, N.C. 27514
Made in Taiwan
www.performancebike.com

PERFORMANCE and the Flying P Logo are registered marks of Performance, Inc.

0902_1

**Performance Tech Support 1(800)727-2453
9am-6pm EST Monday-Friday**

PERFORMANCE[®]**Forté[®]**
STOMP Pedal

Congratulations on your purchase of Forté STOMP Pedals.
To install and adjust your new pedals you will need:

- 15mm pedal wrench
- 2mm hex wrench

Pedal Installation

The right pedal (*marked R*) is installed in a clockwise direction. The left pedal (*marked L*) is installed in a counterclockwise direction.

1. Grease the axle threads prior to installation.
2. Use a 15mm pedal wrench to install and tighten the pedals. Tighten to a minimum of 300 inch/lbs. of torque.
3. To adjust or remove the traction pins, use a 2mm hex wrench.



Performance, Inc.
One Performance Way
Chapel Hill, N.C. 27514
Made in Taiwan
www.performancebike.com

PERFORMANCE and the Flying P Logo are registered marks of Performance, Inc.

0902_1

**Performance Tech Support 1(800)727-2453
9am-6pm EST Monday-Friday**