



Tech Support Line
1-800-727-2453
20-1651 0603_1

installation


Cygnus lens installation



Step 1
Insert the outside corner of the lens into the frame at the temple.



Step 2
Insert the inside corner of the lens into the frame groove near the bridge.




Step 3
While holding the frame and lens, apply pressure to the lower edge of the lens until it snaps into the bridge.


Tech Support Line
1-800-727-2453
20-1651 0603_1

removal


Cygnus lens removal



Step 1
Grip the inside corner of the lens near the bridge.



Step 2
Pull down on the lens to release it from the frame.



Step 3
The entire lens should come away from the frame.