

07/23/08
 Performance ViewPoint
 TriLite LED Headlight
 Artwork @ 100%
 Do not print magenta keylines

LED headlight

- 3 super bright white LED's
- Special focusing lens amplifies light output
- 75+ hour run time
- 2 light modes (steady or flashing)
- Quick release bracket offers 15° of lateral adjustment
- Uses 4 "AA" batteries (included)

LED headlight

- 3 super bright white LED's
- Special focusing lens amplifies light output
- 75+ hour run time
- 2 light modes (steady or flashing)
- Quick release bracket offers 15° of lateral adjustment
- Uses 4 "AA" batteries (included)

PERFORMANCE
 FOR PEOPLE WHO LOVE BIKES™

ViewPoint™

TriLite LED headlight




Performance Inc.
 One Performance Way
 Chapel Hill, NC 27514
 Made in Taiwan
 PerformanceBike.com
 PERFORMANCE and the Flying P are registered marks of Performance Inc.

Tech Support Line 1-800-727-2453

40-1730

4 00010 09091 4

ViewPoint TriLite LED Headlight



Battery Installation

1. Twist rear battery cover counterclockwise to align "OPEN" arrows and pull to remove.
2. Install 4 "AA" (1.5V) batteries in battery case and orient batteries according to diagram inside case.
3. Replace cover by aligning "OPEN" arrows and then twist clockwise to tighten.

Bracket Installation

1. Attach mounting bracket to handlebar as shown in Figure 2. Use supplied rubber shim as necessary to ensure a secure fit.
2. Tighten thumb screw until bracket is secure on handlebar.
3. Attach light to bracket. Slide light onto bracket from front to back. Ensure light is securely attached to bracket before riding.
4. Adjust orientation of bracket so light is positioned in an optimal direction. The light bracket offers 15° of rotation. Use thumb screw to adjust rotation tension.